

Assembly Instructions

Attach OuikClip® to the Bridle Loop.

For light to medium wind conditions. attach only one set of SkyTails® to the center loon located at the bottom of the kite.

For strong wind conditions, attach SkyTails® to outside loops also located at the bottom of the kite. As shown on front of package.

For storage, fold kite neatly and wrap SkyTails® around to prevent tangles.



Flying Instructions

Always select a flying field that is wide open to provide the best fiving conditions.

With your back to the wind, hold up to catch wind and release line slowly. Every now and then a gentle tug will help vour kite climb.

In light wind, have a friend hold your kite downwind about 75 feet / 22.9 m. Have your friend release the kite. then quickly pull in the line hand over hand to gain altitude.



Kite Safety



Never fly near tall buildings or trees.



fly in thunderstorms.



Never flv over neonle.



fly near



WARNING! Do not fly near overhead power lines.





Never

fly near

an airport.

Never flv near overhead power lines. Never try to retrieve your kite from nower lines. Call vour local power company for assistance.